



10

Apply appropriate glue to the male pin



11

Insert the pin into the hole in the edger of the door making sure the radius on the large diameter is in the imaginary arc created by the door as it closes.



12

This will allow for pin clearance as it enters the female socket in the doorframe. Be careful not to let it rotate as you push it into the hole.



13

Seat the pin with a block of wood and hammer until the shoulder of the large diameter is up against the door edge.