

# Deadbolt Side Installation Instructions



1 Temporarily remove the Deadbolt Striker-plate.



2 Install Template "C" using Striker-plate screws.



3 Mark inside the rectangular hole and remove the Template.



4 Route the marked area, removing the pencil mark. This may be done by drilling, wood chiseling, or using a hand router. Route or chisel to 1 ½" Deep.



5 Install Drill Guide "D" and secure with wood screw furnished in kit.

# Deadbolt Side Installation Instructions



6

Use a ½" Drill. Keeping the drill level and in line with the Drill Guide angle, drill the ½" hole to a depth of 5 ¼" from the face of the drill guide. You will be drilling at the proper angle to match the angle on Detail #3.



7

Vacuum Sawdust from hole. Apply appropriate glue to Detail #3 and install in drilled hole.



8

Seat Detail #3 with a hammer and punch to move past the designed interference.



9

Re-install Striker-plate to cover Detail #3.